


WIRING DIAGRAM
with ignition lock
battery
parking lights
flashing indicators



- 1 Headlamp bulb 6 V 35/35 W
- 2 City light (parking light) bulb 6V 1,5 W
- 3 Control bulb 24 V 2 W
- 4 Trafficator switch
- 5 Flashing trafficator
- 6 Ignition lock
- 7 Combined switch

- 8 Horn
- 9 Fuse 4 A
- 10 Speedometer bulb 6V 0,6 W
- 11 Parking light switch
- 12 Rheostat R = 10Ω / 10 W
- 13 Ignition coil
- 14 Flasher

- 15 Flywheel magneto
- 16 Stop switch
- 17 Charging switch
- 18 Rear and stop light 6V 3/15W
- 19 Rectifier
- 20 Fuse 1A
- 21 Battery